



The Veritas® Shooting Grip attaches to either side of a Veritas plane\* that has fence rod holes located in the side of the plane, providing a comfortable handhold when the plane is used on its side for shooting.

As delivered, the shooting grip is configured for right-hand use. For left-handed use, simply unscrew the horn and attach it to the other side of the base plate, as shown in **Figure 1**. The mounting screws are held in place using O-rings. Slide them off the screws and install from the other side.



**Figure 1: Configuring the shooting grip for left-handed use.**

To install the shooting grip, align the slots in the base plate with the fence rod holes in the side of the plane, and secure with the mounting screws, but do not fully tighten them at this time.



**Figure 2: Installing the shooting grip onto a plane.**

Place the plane on your shooting board and adjust the location of the shooting grip fore and aft until a comfortable grip is achieved. Tighten the mounting screws.

\*The shooting grip will fit onto the following planes:

- #5 Jack Plane (06P05.71A and all custom versions)
- #5½ Jack Plane (06P15.71A and all custom versions)
- #7 Jointer Plane (06P07.71A and all custom versions)